Bumpon™
Protective Products

Installation Instructions

1. Apply to any smooth, flat unified surface such as glass, metal, wood, smooth plaster, tile, etc.
2. For best results, surfaces must be clean and dry. Clean with a low strength solvent like isopropyl alcohol (rubbing alcohol) or heptane (white gas) with clean cloth.
3. Do not attempt to use on fabric, coarse concrete walls, rough sand finishes, loose paint or rough wallpaper.
4. Remove paper liner from back of bumper. Avoid touching adhesive with fingers. Place bumper on desired location and PRESS FIRMLY to insure good contact of adhesive.

Important notice to purchaser: All statements, technical information and recommendation herein are based on tests we believe to be reliable, but the accuracy or completeness thereof is not guaranteed, and the following is made in lieu of all warranties, expressed or implied, including the implied warranties of merchantability and fitness for purpose: Seller's and manufacturer's only obligation shall be to replace such quantity of the product proved to be defective. Before using, user shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith. NEITHER SELLER NOR MANUFACTURER SHALL BE LIABLE EITHER IN TORT OR IN CONTRACT FOR ANY LOSS OR DAMAGE, DIRECT, INCIDENTAL, OR CONSEQUENTIAL, ARISING OUT OF THE USE OF OR THE INABILITY TO USE THE PRODUCT. No statement or recommendation not contained herein shall have any force or effect unless in an agreement signed by officers of seller and manufacturer.

"Bumpon" in a reg. T.M. of 3M, St. Paul, MN 55144

3M